FIG.1



FIG.2



EP 2 374 603 A1

FIG.3


100
314
311
KEY BOARD
DISPLAY
301
313
310
CPU
KEY BOARD CONTROLLER
DISPLAY CONTROLLER
302 DATA BUS
304
305
306
310
CARD BUS CONTROLLER
ROM
RAM
HARD DISK CONTROLLER
312
303 CARD BUS
308
309
HARD DISK DRIVE
NETWORK INTERFACE CARD
IMAGE DATA NETWORK INTERFACE CARD

FIG.4


102
901
902
903
CPU
ROM
RAM
904 CPU BUS
905
908
909
IEEE1394 LINK CONTROLLER
FIFO
VIDEO DATA CONTROLLER
912
910
PRINTER ENGINE
LASER DRIVER
906
IEEE 1394 PHYSICAL INTERFACE
911
913
ENGINE CONTROLLER
IMAGE COMPARING CIRCUIT
907 CONNECTOR
914
SPECIFIC IMAGE MEMORY
1001 IMAGE NETWORK

FIG.5



FIG.6

DEVICE NAME	FORGERY - PREVENTING FUNCTION
101 SCANNER	○
102 PRINTER	○
103 SCANNER	×
104 PRINTER	×

FIG.7


START
S401
INPUT IMAGE READING INDICATION OR NOT ?
NO
YES
S402
STARTING TO SCAN
S403
IMAGE COMPARING
S404
COINCIDENCE DEGREE > PREDETERMINED VALUE ?
YES
NO
S406
SENDING INFORMATION INDICATING SPECIFIC IMAGE IS READ
S407
DISPLAY WARNING
S405
SENDING IMAGE DATA
S408
PRINTING
END

09154421 "02/27/01

FIG.8



FIG.9


START
S601
INPUT IMAGE READING INDICATION OR NOT ?
NO
YES
S602
STARTING TO SCAN
S63
SENDING IMAGE DATA
S604
IMAGE COMPARING
S605
COINCIDENCE DEGREE > PREDETERMINED VALUE ?
YES
NO
S607
DISPLAY WARNING
S606
PRINTING
END

FIG.10



FIG.11



0915421 - 07/27/01

FIG.12


SCAN–PRINT JOB
SCANNER
101 SCANNER
PRINTER
102 PRINTER
104 PRINTER

FIG.13


SCAN–PRINT JOB
SCANNER
103 SCANNER
PRINTER
102 PRINTER

FIG.14


START
S901
INPUT AN INDICATION FOR SELECTING SCANNER OR NOT ?
NO
YES
S902
CHANGING DISPLAY CONDITION FOR SCANNERS EXCEPT THE SELECTED SCANNER
S903
THE SELECTED SCANNER HAS THE FORGERY-PREVENTING FUNCTION OR NOT ?
NO
S905
DISPLAYING PRINTERS HAVING THE FORGERY-PREVENTING FUNCTION AS AVAILABLE PRINTERS
YES
S904
DISPLAY ALL PRINTERS AS AVAILABLE PRINTERS
END